List of storage features

▶ 5-seat models

1 Glove box
2 Auxiliary boxes
3 Door pockets
4 Cool box/auxiliary box (if equipped)
5 Cup holders
6 Console box
7 Coin holder

▶ 4-seat models

1. Glove box
2. Auxiliary boxes
3. Door pockets
4. Cool box
5. Cup holders
6. Console box
7. Coin holder

Glove box

1 Open (push button)
2 Lock with the mechanical key
3 Unlock with the mechanical key

Trunk opener main switch

The trunk opener main switch is located in the glove box. (→ P. 68)

CAUTION

Caution while driving

Keep the glove box closed.
Injuries may result in the event of an accident or sudden braking.

Coin holder

Press in the button.

 CAUTION

Caution while driving

Keep the coin holder closed.
Injuries may result in the event of an accident or sudden braking.

Door pockets (front)

The front door pockets can be opened and closed.

CAUTION

Caution while driving

Keep the door pockets closed.
Injuries may result in the event of an accident or sudden braking.

Cup holders

▶ Front

Press down and release the right side of the cup holder lid.

▶ Rear (5-seat models)

Press in and release the cup holder.

▶ Rear (4-seat models)

Press in and release the button.

CAUTION

- **Items unsuitable for the cup holder**

  Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

- **When not in use**

  Keep the cup holders closed.
  Injuries may result in the event of an accident or sudden braking.

Console box

1. Slide the armrest while pushing the knob.
2. Lift the armrest.

- **Tray in the console box**

The tray can be raised backward.

- **Opening and closing assist function**

  When the console box is opened or closed partway, this function will apply force in the appropriate direction, helping open or close the console box.

CAUTION

■ **Caution while driving**

Keep the console box closed.
Injuries may result in the event of an accident or sudden braking.

 NOTICE

■ **Tray**

Do not insert items exceeding the height of the tray. Doing so may prevent opening and closing of the lid.

Cool box/auxiliary box (if equipped)

▶ 5-seat models

Pull down the armrest.

Pull the lever.

Open the cool air intake lid.

▶ 4-seat models

Pull up the lever to release the lock and lift the lid.

Open the cool air intake lid.

Operating conditions (cool box)

▶ 5-seat models

- The rear air conditioning system is on.
- [icon] is displayed on the rear control panel.

▶ 4-seat models

Using a cool box as an auxiliary box

▶ 5-seat models

Close the cool air intake lid to turn off the cool box system.

▶ 4-seat models

Close the cool air intake lid to turn off the cool box system.

Items unsuitable for the cool box

- Drinks in unsealed containers
- Fragile items, perishables or anything with strong odor

CAUTION

Caution while driving

Always keep the cool box closed to reduce the chance of injury in case of an accident or sudden stop.

Auxiliary boxes

▶ Overhead

Press in the button.

This box is useful for temporarily storing sunglasses and similar small items.

▶ Rear seat (5-seat models)

STEP 1

Pull down the armrest.

STEP 2

1 Press the button to release the lock.

2 Lift the lid.

▶ Rear seat (4-seat models)

Press in the lid.

This box is useful for storing DVD discs and headphones.

 CAUTION

n **Items that should not be left in the auxiliary box (overhead type)**

Do not leave glasses or lighters in the box.
If the interior of the vehicle becomes hot, lighters may explode and glasses may warp or crack.

n **Caution while driving**

Do not leave the auxiliary box open while driving.
Items may fall out and cause death or serious injury in case of an accident or sudden stop.